

## iHome Clean 2.0 Setup Guide for Android

### Step-by-Step Wi-Fi Setup (Quick Start)

#### Getting Started:

1. Download and open the iHome Clean app on your Android device [from this link](https://play.google.com/store/apps/details?id=com.ihome.clean.smart&hl=en_US).  
([https://play.google.com/store/apps/details?id=com.ihome.clean.smart&hl=en\\_US](https://play.google.com/store/apps/details?id=com.ihome.clean.smart&hl=en_US))
2. Ensure your phone is connected to a 2.4GHz Wi-Fi network — not 5GHz — before proceeding. (note: have your WiFi password ready since it will be needed in step 8)
3. Create a new user account in the app and log in. Keep the app open after logging in.
4. Turn on your iHome Autovac pressing and holding the Power button on the robot.

#### Pairing your iHome Autovac in the iHome Clean 2.0 app:

5. Once logged in on the iHome Clean 2.0 app, tap the “+” sign in the top right corner of the home screen and select “Add Device”. *(Note: stay at the top of the screen and keep your app open. Proceed to the step 6 below.)*
6. Now, on your iHome Autovac, press and hold the Home button on the robot for around 5 seconds until the Wi-Fi indicator flashes. That ensures the robot vacuum is in setup mode. (Now, return to the app on your mobile device.)
7. Wait a few seconds for the robot to be recognized by the app. A small circle icon will appear at the top of the Add Device screen. Tap the icon to proceed with setup.
8. On the next screen, you will be prompted to enter the WiFi password of the network that your phone is currently connected to.
9. Once connected, you can control the robot, start cleaning cycles, and adjust settings via the app.