



Hall Stand CF6015



PART LIST



HARDWARE LIST

| #1 | #2 | #3 | #4 | #5 |
|------------------|---------------------|---------------------|--------------|------------------|
| | | | | |
| | Ø6x30 | M6x35 | M4 | Ø7x2.5x12mm |
| Safety Strap Kit | Small Wood Dowel | Allen Bolt | Allen Wrench | Screw |
| 1 PC | 19 PCS (Extra 1) | 23 PCS (Extra 1) | 1 PC | 13 PCS (Extra 1) |
| #6 | #7 | #8 | #9 | #10 |
| | | | | |
| | M4x18 | Ø8x40 | | M6x30 |
| Handle | Round Head Bolt | Large Wood Dowel | Hook | Flat Head Bolt |
| 1 PC | 2 PCS | 9 PCS (Extra 1) | 5 PCS | 5 PCS |

#11



D8*Ø4*25

Long Screw

6PCS (Extra 1)


ADDITIONAL TOOLS (Not Provided)

Note: It is not recommended to use power tools during assembly.




Phillips Head Screwdriver

Please do not use tools to assemble this unit unless specifically indicated.




Reference the images above any time the instructions state "lock the hardware". Note: Be sure to check all hardware is locked when completed.

Step 1. Attach hooks (part #9) to back middle rail (part D) using flat head bolts (part #10) and phillips head screwdriver.




Step 2. Attach handle (part #6) to front of drawer (part I) using round head bolts (part #7) and phillips head screwdriver.


Attach support rail (part R) to top panel of cabinet (part F) using long screws (part




Step 3. Attach left side panel of drawer (part J) and right side panel of drawer (part K) to back panel of drawer (part L) using small wood dowels (part #2) and lock the hardware. Attach bottom rail of drawer (part Q) to back panel of drawer (part L) using small wood dowel (part #2) and lock the hardware. Slide bottom panel of drawer (part M) into the grooves of left side panel of drawer (part J) and right side panel of drawer (part K). Attach front of drawer (part I) to left side panel of drawer (part J), right side panel of drawer (part K), bottom panel of drawer (part M) and bottom rail of drawer (part Q) using small wood dowels (part #2) and lock the



Step 4. Attach left side panel of cabinet (part G) and right side panel of cabinet (part S) to top panel of cabinet (part F) and bottom panel of cabinet (part T) using small wood dowels (part #2) and lock the hardware.




Step 5. Carefully turn unit around, and attach back panel of cabinet (part H) to top panel of cabinet (part F), bottom panel of cabinet (part T), left side panel of cabinet (part G) and right side panel of cabinet (part S) using screws (part #5) and phillips head screwdriver.




Step 6. Attach back top rail (part C), shelf (part E), back middle rail (part D), back bottom rail (part O) and front bottom rail (part N) to left side frame (part A) using large wood dowels (part #8), allen bolts (part #3) and allen wrench (part #4).

Note: Do not completely tighten all allen bolts (part #3), until later on.




Step 7. Attach back top rail (part C), shelf (part E), back middle rail (part D), back bottom rail (part O) and front bottom rail (part N) to right side frame (part B) using large wood dowels (part #8), allen bolts (part #3) and allen wrench (part #4).

Note: Do not completely tighten all allen bolts (part #3), until later on.




Step 8. Insert the cabinet box into hall stand.

Note: Make sure all allen bolts are not completely tightened, or the cabinet box will not fit inside.




Step 9. Attach cabinet box to hall stand using allen bolts (part #3) and allen wrench (part #4). Tighten all allen bolts at this time.




#3 Dannam × 8


#4 X


Step 10. Insert drawer into cabinet box.




Step 11. Put the cushion (part P) into place.







SAFETY STRAP WALL ASSEMBLY INSTRUCTION



- 2) Drill a 11/32"(6mm) hole where you want to secure the unit. The drilled hole will be at the same height as the hole in shelf (part E) where the safety strap is attached. Tap wall anchor (part A) into the hole.
- 3) Insert long screw (part D) through washer (part B) and safety wall strap (part E) into wall anchor (part A) using a Phillips head screwdriver.

