

- Liners: Hand wash only with cold water and mild detergent. Lay flat to dry.
- All other parts: Spot clean only. Unplug and wipe with a damp cloth then allow to air-dry fully. Do not submerge in water. Do not use detergent or soap when cleaning.
- When not using for an extended period of time, close cover and store in a cool dry and dry location.

CARE AND TIPS

- To reduce the risk of electric shock, always unplug this appliance from the electrical outlet immediately after using and before cleaning.



DANGER

CONGRATULATIONS ON YOUR PURCHASE OF THE SHIATSU FOOT + CALF

Keep this instruction manual as it contains important information for future reference.

Due to continuous product improvements, the picture on the manual may differ slightly from the actual product.

SHARPER IMAGE® NAME AND LOGOS (INCLUDING THE 77 LOGO AND TOMORROW'S TOMORROW) ARE TRADEMARKS OR REGISTERED TRADEMARKS. DISTRIBUTED BY AND © 2021 MERCHSOURCE, LLC. IRVINE, CA 92618. ALL RIGHTS RESERVED. FOR CUSTOMER SUPPORT, PLEASE CALL 1-800-374-2744.

Printed in China

SAFETY WARNINGS:

PLEASE READ BEFORE USE

- Not a children's item. Keep out of the reach of children.
- Do not use this item if you are pregnant or have an injury or illness. Consult your physician if you have a medical condition that may prevent safe use of this item.
- As with any massage, bruising may occur. Test your comfort level and check targeted areas often. Stop massage immediately if you feel any increase in physical discomfort or pain.
- Do not use attachments of any kind other than those that may be included.
- Do not fall asleep while using.
- Do not leave this item unattended when it is plugged in.
- Always allow item to cool if it becomes too hot.
- Never operate under blankets where air opening may be blocked. Excessive heat can occur and cause fire, electric shock, or injury to persons.
- Do not expose to extreme temperatures or moisture.
- Keep away from sources of water and heated surfaces.
- Never touch the power plug with wet hands.
- Do not carry this item by its cord.
- For indoor use only.
- Thoroughly inspect products before every use. If the product appears worn, frayed/splintered, cracked, or broken in any manner, discontinue use and discard immediately.



SHARPER IMAGE®

SHIATSU FOOT + CALF

FCC STATEMENT

This device complies with Part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) this device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

NOTE: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/ TV technician for help.

WARNING: Changes or modifications to this unit not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.




CONTENTS


- SHIATSU FOOT + CALF
- Power Adapter

FEATURES

- Rolling shiatsu massage
- Independent heat function
- Air compression


GETTING STARTED

1. Plug the power adapter into the massager and then into a wall outlet.
2. Wear high socks, sit in a chair, and then slide your feet into the massager.
3. Select desired tilt by pressing the center of the button on the right-hand side of the massager.
Note: To use the tilt function, massager must be plugged in.
4. Press the power button to start your massage.
5. Press the  button to toggle through three massage modes; Total, Compression, and Foot.
6. Press the  button to increase or decrease compression intensity.
7. Press the  button to turn heat on or off.
8. Use for no more than 15 minutes a day. Enjoy your massage!



FOLDING COVER

Cover can be triple-folded and held in place with its magnets. Close cover when not in use.



Fold flap and then collapse



Attach flap to magnetic back